


CORRECT INSTALLATION / RICHTIGE MONTAGE

Type / Typ HW/HC




Washer (can be used without cup)

Kugelscheibe (kann auch ohne Kegelpfanne verwendet werden)

Rondelle (peut s'utiliser sans coupelle)



Cup
Kegelpfanne
Coupelle



Ref: HWHC_SEP19

Product Code Artikelnummer Code Produit		Rod Gewindestange Tige	Hemispherical Washer Kugelscheibe HW Rondelle hémisphérique		Hemispherical Cup Kegelpfanne HC Coupelle hémisphérique		Hemispherical Washer and Cup Kugelscheibe und Kegelpfanne Rondelle et coupelle hémisphériques	
Washer Kugelscheibe Rondelle	Cup Kegelpfanne Coupelle	Z	X	W1	Y	W2	R	L
			mm	mm	mm	mm	mm	mm
HW10	HC10	M10	25	12	32	12	13	16
HW12	HC12	M12	29	12	35	12	14	18
HW16	HC16	M16	34	16	41	16	17	22
HW20	HC20	M20	44	19	54	19	22	24

Product Code		Rod	Hemispherical Washer		Hemispherical Cup		Hemispherical Washer and Cup	
Washer	Cup	Z	X	W1	Y	W2	R	L
LHW037	LHC037	3/8"	1"	1/2"	1 1/4"	1/2"	1/2"	5/8"
LHW050	LHC050	1/2"	1 1/8"	1/2"	1 3/8"	1/2"	9/16"	1 1/16"
LHW062	LHC062	5/8"	1 3/8"	5/8"	1 5/8"	5/8"	1 1/16"	7/8"
LHW075	LHC075	3/4"	1 3/4"	3/4"	2 1/8"	3/4"	7/8"	1 5/16"